

## PUTTY/FILLER

### 83-4002 [ Heavy Polyester Putty BBP ]

#### 1. GENERAL INFORMATION

Plastic Body filler that, 2 components Unsaturated polyester. It's providing excellent adhesion to all metals. In addition, it can be applied direct to metal or on primer. It's can be used as heavy build filler without affecting the gloss of top/base coat.  
Packing Size : -

#### 2. MIXING

##### COMPONENTS

83-4002 ( Heavy Polyester Putty BBP )

MIX RATIO	Volume	By weight	Remark
83-4002	100	185.00	
Gel Time	3 - 6 minute		

#### 3. APPLICATION

##### SURFACE PREPARATION

All surfaces must be thoroughly sanded and cleaned with Concept Wax & Grease Remover prior to application.

-With soap and water. Rinse and wipe dry with clean cloth. Finally, clean surface using Wiping Solvent #85-4 (slow) or #85-7 (fast) with clean cloth.

-Sand steel, aluminum, or galvanized metal with 150 – 240 grit sandpaper. Primer can be applied direct to metal

-OEM or Original Paint must be cured and sanded with 150 – 240 grit sandpaper. Clear or lacquer must be sanded with 150 – 240 grit sandpaper before to avoid lifting. Body filler or fiberglass must be sanded with 150 – 240 grit sandpaper.

##### APPLICATION

Apply smooth film immediately after mixing, avoiding air entrapment. In the case of High dry film putty required, recommended to apply thin film with many of paint layers.

#### 4. DRY TIME

##### AIR DRY @25-30 °C

Dry for wet sanding : 45 - 60 minutes

Dry for Dry sanding : Contact our Technician

##### FORCE DRY at 60-80 °C

Flash off before forcing dry : 3 - 5 minutes

Cycle Time : 10 - 15 minutes

Cool Down : 10 – 15 minutes

##### INFRARED DRY

Refer to the Infrared Guide for setup recommendations.

Remark : Flash time and Dry times will depends on temperature, humidity and wet film thickness.

This data relates only to the material designated herein and does not apply to use in combination with any other material or any process. The data is not to be considered as a warranty or quality specification and assume no liability in connection with its use.

#### 5. SANDING

##### SANDING

Prior to Topcoat

By wet sanding step #P800-#P1000 before apply Topcoat

-Initial sanding steps may be executed with a coarser sanding grit #P600 – #P800

By dry sanding by #P500 - #P800 before apply Topcoat

-Initial sanding steps may be executed with a coarser sanding grit #P320 to #P400



## PUTTY/FILLER

83-4002 [ Heavy Polyester Putty BBP ]

### 6. PHYSICAL PROPERTIES

---

Specific Gravity : 1.75 - 1.85 g/cm<sup>3</sup>

### 7. VOC REGULATION AREAS

---

These directions refer to the use of products which may be restricted or require special mixing instruction in VOC regulation areas. Follow mixing usage and recommendations in the VOC compliant products Chart for your area.

### 8. SAFETY AND HANDLING

---

For professional or trained applicator use only. Not for sale or use by the public. Before use, read and follow all TDS, label, and SDS precautions. Flammable product. Keep out of reach of children. Always wear approved organic vapor goggles and a safety mask when using a product. Apply paint in good ventilating area.